


# iPadから印刷する方法

■補足

iOSのバージョンによっては、[↵] や [⋮] の場合があります。

1. 印刷したいワークフロー画面を表示し、 を押します。



2. [プリント] を押します。



■補足

[プリント]が見つからない場合は、画面を左にフリックして [プリント] を表示させます。



3. [プリンタを選択>] を押します。



4. 使用する機器を選択し、[<オプション] を押します。



5. 必要に応じて印刷設定をし、[プリント] を押します。

The image shows a printer's control panel interface. At the top, there are three buttons: "キャンセル" (Cancel) on the left, "オプション" (Options) in the center, and "プリント" (Print) on the right, which is highlighted with a red rectangular box. Below these buttons, the printer model "RICOH" is displayed with a right-pointing arrow. The next section shows the page count "1部" (1 page) with a minus sign button on the left and a plus sign button on the right. Below that, the range is set to "範囲" (Range) with "すべてのページ" (All pages) and a right-pointing arrow. The main display area shows a preview of a document with the Ricoh logo and the slogan "imagine. change." Below the preview, there is a small image of a printer and some text in Japanese. On the right side of the preview area, there are additional settings for "ページ数" (Page count) and "印刷範囲" (Print range).

プリンターによっては、

iPadで印刷できない場合もあります。